

How to Install Bunji Loops to Blank Tonneaus or Trailer Covers

Please read all the instructions before commencing installation.



PUNCH



BUNJI



EYELET

STEP ONE:

Ensure that a small hole (4mm) has been punched into the tonneau or trailer cover (if installing to a new blank cover).

If you are installing bunji loops for a tonneau or trailer cover that has previously had bunji's fitted, drill out the old bunji cord eyelet from the cover.

STEP TWO:

Place the bunji eyelet through the hole in the tonneau with the flat bottom underneath and the post sticking through the top of the cover.

STEP THREE:

Place the bunji cord assembly onto the eyelet with the fabric in between the eyelet and the bunji cord assembly.

STEP FOUR:

Place the punch on the eyelet post and hit with a hammer to ensure the eyelet crimps and closes to secure the bunji cord into place.

Most 'Blank' tonneau covers purchased from Coverworld.com.au include a Punch (please check the product details/contents to be sure) however our Trailer Covers do not, and must be purchased separately, if required. Bunji Punches (also known as a 'Durable Eyelet Punch'), can be purchased from Coverworld.com.au.