

STANDARD BUNJI LOOPS

If you still have your existing Soft Tonneau Cover then we expect you will install the bunji loops in the same position as before. In Order to determine the correct length Bunji Loops you will require for your Soft Tonneau Cover please measure the distance from the top of the Bunji Loop to the bottom of the installed button. When receiving a Blank Tonneau Cover the Bunji loops will need to be installed 40mm from the bottom of the cover.

